


AIR BRAKE PARTS

12 AIR BRAKE CAMSHAFTS


JK0603 Ford
JK0604 GM
JK0605 IH
JK0606 Blue Bird
JK0607 Freightliner




1. Measure "L" (under head to snap ring at splined end).
2. Specify LH or RH of bus.
3. Count no. of splines.

13 AIR BRAKE HOSES

LK0046 Ford
LK0045 GM
LK0047 IH
LK0048 Blue Bird
LK0049 Freightliner



Compressor
Oil Feed Hose



Compressor
Air Discharge
Hose






Compressor
Oil Drain
Hose

14 AIR BRAKE CHAMBERS



FRONT

LK5279 Ford
LK5281 GM
LK5284 IH
LK5278 Blue Bird
LK8624 Freightliner






REAR

LK5280 Ford
LK5283 GM
LK5277 IH
LK5282 Blue Bird
LK8728 Freightliner



15 ABS MODULATORS AND CONTROL MODULES




JK0608 Ford
JK0609 GM
JK0610 IH
JK0611 Blue Bird
JK0612 Freightliner



16 AIR BRAKE SHOES



FRONT

LK5300 Ford
LK5303 GM
LK5305 IH
LK5301 Blue Bird
LK8628 Freightliner



REAR


LK5309 Ford
LK5302 GM
LK5304 IH
LK5298 Blue Bird
LK8623 Freightliner



17 AIR BRAKE DRUMS

FRONT

LK5307 Ford
LK5317 GM
LK5311 IH
LK5324 Blue Bird
LK8622 Freightliner






REAR

LK5310 Ford
LK5306 GM
LK5314 IH
LK5316 Blue Bird
LK8626 Freightliner

18 HARDWARE KITS

LK5323 Ford
LK5312 GM
LK5318 IH
LK5315 Blue Bird

Note: Components in various
Hardware Kits may be different
from those shown below.



19 BUSHING KITS

LK5313 Ford
LK5319 GM
LK5325 IH
LK5308 Blue Bird

Note: Components in various
Bushing Kits may be different
from those shown below.

